




INSTRUCTION MANUAL
CAT-BACK DUAL SPORT TRUCK EXHAUST
99-02 FORD EXPEDITION/NAVIGATOR 4.6L- 5.4L 2/4WD
PART# 9600



ITEM	PART #	QUANTITY	DESCRIPTION
A	700176	1	3" HEADPIPE
B	758250	1	SUPERFLOW MUFFLER
C	700186-1	1	2-1/4" FRONT DRIVERS SIDE TAILPIPE
D	700186-2	1	2-1/4" DRIVERS SIDE OVERAXLE TAILPIPE
E	700187-1	1	2-1/4" FRONT PASSENGER SIDE TAILPIPE
F	700187-2	1	2-1/4" PASSENGER SIDE OVERAXLE TAILPIPE
G	500370	2	3" STAINLESS TIP
H	5757	3	2-1/2" CLAMP
I	5756	2	2-1/4" CLAMP
J	OHD300	1	3" CLAMP
K	40083	1	REAR MUFFLER T-HANGER
L	BO-906	1	BOLT KIT FOR TAILPIPE

Thank you for purchasing our GIBSON EXHAUST SYSTEM for your vehicle. If you need further assistance, please do not hesitate to call our Technical Department at (800) 528-3044, Monday through Friday, 8:00 am to 5:00 pm. 0706

EXHAUST INSTALLATION PART #9600

WHEN INSTALLING THIS EXHAUST SYSTEM ,MAKE SURE TO USE PROPER SAFETY PRECAUTIONS.USE JACK STANDS WHEN UNDER THE TRUCK, SET PARKING BRAKE, BLOCK TIRES AND USE SAFETY GLASSES AND GLOVES. DO NOT WORK WITH HOT PIPES!

SUGGESTED TOOLS

9/16 " , $\frac{1}{2}$ " , 15 MM WRENCH AND SOCKET, WD-40, HACKSAW OR SAWZALL, JACKSTAND



Lay out the exhaust on the floor so it looks like the drawing and compare parts with manual. **To remove the stock exhaust, un-clamp it just in front of the muffler.** You may need to heat it up for easier removal. Leave all rubber grommets in place. Use WD-40 to aid in removal of exhaust and the hangers. Now cut off your stock tailpipe just behind the muffler



Install the passenger side front tailpipe #E $1\frac{1}{2}$ " to 2" into muffler. Use clamp # H to secure front tailpipe to muffler, and attach hange # K. Do not tighten.



Install head pipe #A onto your existing stock front pipe and secure with clamp #H. Use a jack stand to support the converter. Do not tighten.



Install drivers side front tailpipe #C into muffler $1\frac{1}{2}$ " to 2". Use clamp #H to secure front tailpipe to muffler. Do not tighten.




Install muffler #B onto head pipe $1\frac{1}{2}$ " to 2" with the louvers facing towards the converter. Use a jack stand to support the muffler. Use clamp #J to secure the muffler to the head pipe. Do not tighten. Outlets should be on the bottom.



Install passenger side overaxle tailpipe #F onto front tailpipe using clamp #I to secure pipes together. Do not tighten. Slide welded hanger into rubber grommet



Install rear muffler-T-hanger #K into rubber grommets located just above the muffler outlets. Shorter side of the hanger will be inserted on the passenger side grommet. Slide clamp onto passenger side muffler outlet. Do not



Install drivers side overaxle tailpipe #D onto front tailpipe Use clamp #I to secure together. Do not tighten. Use bolt kit #L to secure pipes together. Tab on drivers' side tailpipe will be on top.



Install the stainless steel tips. Clamp down. To clean your stainless tips, use a scotch brite pad and any stainless steel or aluminum cleaner. Now go back and tighten all clamps, nuts and bolts. Start from the front and work back.

MAKE SURE YOU HAVE A 1" CLEARNACE ON ALL RUBBER BRAKE LINES, SHOCK BOOTS, TIRE, FUEL LINES, ETC...