



Description: Third brake light
Part Number: 531013- 531019
Application: 1995-2004 Toyota Tacoma



Tools needed: 14mm socket, flat head screwdriver, phillips screwdriver, 10mm deep socket.



Use the flat head screwdriver to remove the seatbelt cap cover.



Use the 14mm socket to remove the bolt holding in the seat belt.



Pull back the plastic trim off from the vehicle.



Pull back the seat belt cover trim from the vehicle.



Use the flat head screwdriver to remove the push pins holding the headliner in place.



Use the 10mm deep socket to remove the two nuts holding in the 3rd brake light.



Pull out the 3rd brake light from the vehicle.



Unclip the light from the wire harness.



Put in the supplied screw holder on to the original hole for the bolts.



Peel off the protective backing of the new 3rd brake light.



Plug in the new tail light wire harness.



Use the supplied screws to install the new led 3rd brake light.



Test all functions for proper installation before driving.

AnzoUSA™ products are covered, by a limited one (1) year warranty, to be free of manufacturer's defects. However, certain AnzoUSA™ product categories have warranty policies which differ from this standard, please contact your representative for detailed category information. Damage due to improper installation or road hazards is not covered. Seller and manufacturers' only obligations shall be to replace the product proven to be defective. Neither seller nor manufacturer shall be liable for any injury, loss or damage, direct or consequential, arising out of the use of or the inability to use the product. Before using, user shall determine the suitability of the product for its intended use, and user assumes all risk and liability whatsoever in connection therewith.